

INSTALLATION INSTRUCTIONS

504-42 & 514-48 QSE Styling Station

Hardware Included:

1/4" x 20 x 1 1/2" bolts (6)

5/8" screws (8)

mirror clips (4)

1. Carefully remove all components from both cartons and verify there has been no shipping damage. Locate the right half cabinet assembly with the tool holders, left half cabinet assembly with the double purse ledge, and the fasteners.
2. Align the two cabinet assemblies so that they are flush along the unfinished back and so that the threaded inserts align with the holes. Bolt the two cabinet assemblies together with the six 1/4" phillips head bolts provided. Turn the chrome door and drawer pulls outward for use.
3. Install the mirror clips to the wall using the appropriate type of fasteners for the construction materials. Hang mirror inside the mirror clips. The recommended mirror is 42" wide x 36" tall.
4. Recycle or properly dispose of packaging materials.