


1. **Attach lower cabinet to the wall with fasteners provided.**
2. **Attach French cleat for drawer unit to the wall.**
3. **Lower the drawer unit onto the rear and side French cleats.**
4. **Attach drawer unit with fasteners provided.**
5. **Set upper retail/tool units on top of lower cabinets and attach with the fasteners provided.**
6. **Attach French cleat for mirror to the wall and install mirror. Attach upper retail/tool unit to the wall and mirror.**
7. **Electrical power enters into lower cabinet through the back and passes up into tool panel area.**

Quantity - 1

Finish Schedule - 831-54-1
Face Color -
Face Frame Color -
Legs -
Pulls -
Interior -
Reveals -

Installation Notes:
1. All hardware needed for assembly is included.
2. Large items are preassembled at the factory to ensure proper alignment. Items are then disassembled into manageable sections for shipping purposes and ease of reassembly.
3. Shipping cleats need to be removed before installation. These cleats are installed to prevent damage.

 Collins Manufacturing 2000 Bowser Rd. Cookeville TN 38506		
Title:		
Date:	at:	Drawn By:
Date: 09/18/05	Sheet #: 10	