

1. Bolt two drawer together back to back.
2. Set lower cabinets in place.
3. Lower the drawer unit into place on the cleats.
4. Attach drawer unit with wood fasteners provided.
5. Set upper retail/tool units on top of lower cabinets and attach with the fasteners provided.
6. Set mirror in place and attach through the retail display with the fasteners provided.
7. Electrical power enters through top center of the mirror and passes straight down between the two purse ledge halves. Then it goes straight over to cabinets and up to the outlets.


Quantity - 1

Finish Schedule - 832-72-1

Face Color -
 Top Color -
 Legs -
 Pulls -
 Interior -
 Reveals -

General Notes:

1. All counter tops are to be made removable wherever possible.
2. Items must be broken into manageable sections For Shipping. Mark For Ease Of Reassembly.
3. Install Shipping Cleats Wherever Possible To Prevent Shipping Damage.
4. Purchased items Must Be Trial Fit Before Shipping.

		Collins Manufacturing 2000 Bowser Rd. Cookeville TN 38506	
Title:			
Size:	#:	Drawn By:	
Date: 03/23/05			Sheet #: 10